




25 Litre Built-in Microwave Oven Instruction Manual

SBIM30X

Read the Instructions carefully and Keep for Future Reference



IMPORTANT SAFETY INSTRUCTIONS

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

-WARNING – Accessible parts may become hot when the grill is in use. Children should be kept away.

- During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.

-Do not use harsh abrasive cleaner or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

-The oven must be switched off before removing the guard.

- WARNING – Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.

WEEE symbol instruction

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

SPECIFICATIONS

Power consumption:	240V~50Hz, 1300W
Output:	800W
Grill Heater:	950W
Operating Frequency:	2,450MHz
Outside Dimensions:	592mm(W) X 390mm(D) X 380mm(H)
Oven Cavity Dimensions:	330mm(W) X 330mm(D) X 215mm(H)
Oven Capacity:	25 litres
Uncrated Weight:	Approx. 17.6kg

BEFORE YOU CALL FOR SERVICE

1. If the oven will not perform at all, the display does not appear or the display disappears:
 - a) Check to ensure that the oven is plugged in securely. If it is not, remove the plug from the outlet, wait 10 seconds and plug it in again securely.
 - b) Check the premises for a blown circuit fuse or a tripped main circuit breaker. If these seem to be operating properly, test the outlet with another appliance.
2. If the microwave power does not function:
 - a) Check to see whether the timer is set.
 - b) Check to make sure that the door is securely closed to engage the safety interlocks. Otherwise, the microwave energy will not flow into the oven.

IF NONE OF THE ABOVE RECTIFIES THE SITUATION, THEN CONTACT THE AUTHORIZED SERVICE AGENT.

Note:

The appliance is for household use for heating food and beverages using electromagnetic energy and for indoor use only.

-This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and Knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

RADIO INTERFERENCE

Microwave oven may cause interference to your radio, TV, or similar equipment. When interference occurs, it may be eliminated or reduced by the following procedures.

- a. Clean the door and sealing surface of the oven.
- b. Place the radio, TV, etc. as far away from your microwave oven as possible.
- c. Use a properly installed antenna for your radio, TV, etc. to get a strong signal reception.

INSTALLATION

1. Make sure all the packing materials are removed from the inside of the door.
2. Inspect the oven after unpacking for any visual damage such as:
 - Misaligned Door
 - Damaged Door
 - Dents or Holes in Door Window and Screen
 - Dents in CavityIf any of the above are visible, DO NOT use the oven.
3. This Microwave Oven weighs 17.6 kg and must be placed on a horizontal surface strong enough to support this weight.
4. The oven must be placed away from high temperature and steam.
5. DO NOT place anything on top of the oven.
6. DO NOT remove the turn -table drive shaft.
7. As with any appliance, close supervision is necessary when used by children.

WARNING-THIS APPLIANCE MUST BE EARTHED.

1. The plug socket should be within easy reach of the power cord
2. This oven requires 1.5 KVA for its input. Consultation with service engineer is suggested when installing the oven.

CAUTION: This oven is protected internally by ac 250V, 10 Amp Fuse.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow	: Earth
Blue	: Neutral
Brown	: Live

As the colours of the wires in the mains leads of the appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol \perp coloured green or green-and-yellow.

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

IMPORTANT SAFETY INSTRUCTIONS


- WARNING: When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated; (Only for the model with grill function)
- WARNING: If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person;
- WARNING: It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy;
- WARNING: liquids and other foods must not be heated in sealed containers since they are liable to explode.
- WARNING: Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use;
- The oven must have sufficient air flow. Keep 10 cm space at back; 15 cm at both sides and 30cms from top of the oven. Don't remove oven's feet, do not block air events of the oven.
- Only use utensils that are suitable for use in microwave ovens.
- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition;
- If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames;
- Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container;
- The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns;
- Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended;
- When cleaning surfaces of door, door seal, cavity of the oven, use only mild, nonabrasive soaps, or detergents applied with a sponge or soft cloth.
- The oven should be cleaned regularly and any food deposits removed;
- Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation;
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

SAFETY INSTRUCTIONS FOR GENERAL USE

Listed below are, as with all appliances, certain rules to follow and safeguards to assure top performance from this oven:

1. Always have the glass tray, roller arms, coupling and roller track in place when operating the oven.
2. Do not use the oven for any reason other than food preparation, such as for drying clothes, paper, or any other nonfood items, or for sterilizing purposes.
3. Do not operate the oven when empty. This could damage the oven.
4. Do not use the oven cavity for any type of storage, such as papers, cookbooks, etc.
5. Do not cook any food surrounded by a membrane, such as egg yolks, potatoes, chicken livers, etc without first being pierced several times with a fork.

6. Do not insert any object into the openings on the outer case.
7. Do not at any time remove parts from the oven such as the feet, coupling, screws, etc.
8. Do not cook food directly on the glass tray. Place food in/on proper cooking utensil before placing in the oven.
9. **IMPORTANT-COOKWARE NOT TO USE IN YOUR MICROWAVE OVEN**
 - Do not use metal pans or dishes with metal handles.
 - Do not use anything with metal trim.
 - Do not use paper covered wire twist-ties on plastic bags.
 - Do not use melamine dishes as they contain a material which will absorb microwave energy. This may cause the dishes to crack or char and will slow down the cooking speed.
 - Do not use Centura Tableware. The glaze is not suitable for microwave use. Corelle Livingware closed handle cups should not be used.
 - Do not cook in a container with a restricted opening, such as a pop bottle or salad oil bottle, as they may explode if heated in a microwave oven.
 - Do not use conventional meat or candy thermometers. There are the thermometers available specifically for microwave cooking. These may be used.
10. Microwave utensils should be used only in accordance with manufacturer's instructions.
11. Do not attempt to deep-fry foods in this oven.
12. Please remember that a microwave oven only heats the liquid in a container rather than the container itself. Therefore, even though the lid of a container is not hot to the touch when removed from the oven, please remember that the food/liquid inside will be releasing the same amount of steam and/or spitting when the lid is




- (1) Door Safety Lock System
- (2) Oven Window
- (3) Minicrystal panels
- (4) Door button
- (5) Control Panel
- (6) Display window
- (7) Steam cookier
- (8) Grill rack

take out "Grill rack" from Steam cookier before you use "Steam cookier", it is only for "Grill" Function.

- removed as in conventional cooking.
13. Always test the temperature of cooked food yourself especially if you are heating or cooking food/liquid for babies. It is advisable never to consume food/liquid straight from the oven but allow it to stand for a few minutes and stir food/liquid to distribute heat evenly.
14. Food containing a mixture of fat and water, e.g. stock, should stand for 30-60 seconds in the oven after it has been turned off. This is to allow the mixture to settle and to prevent bubbling when a spoon is placed in the food/liquid or a stock cube is added.
15. When preparing/cooking food/liquid and remember that there are certain foods, e.g. Christmas puddings, jam and mincemeat, which heat up very quickly. When heating or cooking foods with a high fat or sugar content do not use plastic containers.
16. Cooking utensil may become hot because of heat transferred from the heated food. This is especially true if plastic wrap has been covering the top and handles of the utensil. Potholders may be needed to handle the utensil.
17. To reduce the risk of fire in the oven cavity:
 - (a) Do not overcook food. Carefully attend microwave oven if paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - (b) Remove wire twist-ties from bags before placing bag in oven.
 - (c) If materials inside the oven should ignite, keep oven door closed, turn the oven off at the wall switch, or shut off power at the fuse or circuit breaker panel.


COMPUTER CONTROL PANEL



Operation Instruction

1. Steam function

1). Basic process



2). You can press "Steam" button from 8 steam menus (refer to table 1)

For Example: select q-1 mode (steam bread) steam 500g food

Step:

1. press " steam " button select q-1 mode
2. Rotation "time setting" select the weight of 500g food
3. press " start/reset " button to steam

Menu	Display
steamed bread	q-1
steamed corn	q-2
steamed fish	q-3
steamed custard	q-4
steamed egg	q-5
steamed sweet potato	q-6
steamed shrimp	q-7
steamed crabs	q-8

Table 1

2. Single Button Heating

Only with a single press of a button, you can start simple cooking, it is very convenient and quick to heat a glass of water etc.

Example: To heat a glass of milk

- a) Put a glass of milk into the cavity and close the door.
- b) Press the button "Start/Reset", the microwave oven will work on 100% power for 1 minutes.
- c) You will hear 5 beeps when cooking is completed.

3. Microwave Heating

This function has two options.

1) Quick microwave heating (100% power)

Example: to heat food on 100% power for 5 minutes

- a) Set cooking time to "5:00"
- b) Press "Start/Reset"

2) Manual-operation microwave heating

Example: To heat food on 70% power for 10 minutes

- a) Press "Micro" button, select "70%" power;
- b) Set time cooking to "10:00"
- c) Press "Start/Reset"

There are 5 power levels and the longest microwave heating time is 60 minutes.

Touching times	Microwave power	Display
1	100%	P-1
2	70%	P-2
3	50%	P-3
4	30%	P-4
5	10%	P-5

4. Auto weight defrost

Select the food type and weight, it will automatically help you to adjust the power level and time.
Example: defrost 500g frozen meat.

- a) Press the button "defrost", "dEF" will be displayed.
- b) Rotate the knob "Time setting" to set the weight 500g.
- c) Press "Start/Reset"

The weight of food must be less than 1000g.

5. Auto-Menu

You only need to select the food type and weight, it will automatically adjust the power and time.

Example: Auto cooking 400g fish

- A) Press "Auto menu" button until "A-5" display
- B) Rotate the knob "Time setting" until "400" display.
- C) Press "Start/Reset"

Touching Times	Menu	A-1	A-2	A-3	A-4	A-5	A-6
		Rice	Vegetable	Meat	Spaghetti	Fish	Chicken
1		100	100	200	1	100	200
2		200	200	300	2	200	400
3		300	300	400		300	600
4		400	400	500		400	800
5		500	500	600		500	1000
6			600	800		600	1200
7				1000		700	1400
8						800	1600
9						900	1800
10						1000	2000

Table 2

6. Grill

This function has two patterns, you may press "Grill/Combi" to select such functions: (the longest cooking time is 60 minutes).

Pattern 1: 100% grill power, display G-1

Example: Cooking food with G-1 for 20 minutes

A) Press "Grill/Combi" until the LED displayed "G-1".

B) Set cooking time "20:00"

C) Press "Start/Reset"

When grilling, the food isn't heated by microwave, heat is radiated from the metal heater at the top of the oven.

When grill is working, the cooking time has 2 stages, after the 1st half of the cooking, the program will automatically pause and sound 2 beeps, indicating you to open the oven and turn food over, close the door after turn the food over, press "Start/Reset" button, the cooking will continue for the 2nd half. If you do not want to turn the food over, the oven will re-start after 1 min pause.

7. Combination Cooking

This appliance offers you a choice of two methods of combination cooking.

Option 1: (20% Micro + 80% Grill), display "C-1"

Option 2: (80% Micro + 20% Grill), display "C-2"

Example: Cooking food using option 2 for 30 minutes.

a) Press "Grill/Combi" button to select "C-2"

b) Set cooking time for 30 minutes

c) Press "Start/Reset"

8. Clock

The oven can be used as a clock.

Example: to input current time 16:30

A) Press "Clock/Timer", the clock symbol will flash in display. Rotate the "Time setting" knob to set "16:00".

B) Press "Clock/Timer" again, rotate the "Time setting" knob to set "16:30"

C) Press "Clock/Timer" again, the clock setting is finished, the time start to go on working.

9. Timer

The timer function helps the microwave oven begin automatic cooking at set time, and automatically stop operation after finishing cooking. (You should set the clock before using timer function).

Example: the current time of microwave oven is 16:30, to set cooking at 18:15 on 70% power for 10 minutes.

A) Press "Timer" and set time to 18:15 (same procedure as setting clock).

B) Press "Micro" to set 70% power.

C) Input cooking time 10 minutes by rotating the knob "Time Setting".

D) Press "Start/Reset".

If you don't set power and cooking time (omit B and C steps), and directly press "Start/Reset" button, the microwave oven will work only as a clock, there will be 10 beeps at 18:15, but no other function will run.


10. Child-safety lock

To activate the child safety lock, press "Auto Menu" and "Clock/Timer" button at the same time for 2 seconds.

Press "Auto Menu" and "Clock/Timer" button, at the same time for 2 seconds again, it will unlock this function.


CARE OF YOUR MICROWAVE OVEN

1. Turn the oven off and remove the power plug from the wall socket before cleaning.
 2. Keep the inside of the oven clean. When food splatters or spilled liquids adhere to oven walls, wipe with a damp cloth. The use of harsh detergent or abrasives is not recommended.
 3. The outside oven surface should be cleaned with a damp cloth. To prevent damage to the operating parts inside the oven, water should not be allowed to seep into the ventilation openings.
 4. Do not allow the Control Panel to become wet. Clean with a soft, damp cloth. Do not use detergents, abrasives or spray-on cleaners on the control Panel.
 5. If steam accumulates inside or around the outside of the oven door, wipe with a soft cloth. This may occur when the microwave oven is operated under high humidity conditions and in no way indicates malfunction of the unit.
 6. It is occasionally necessary to remove the glass tray for cleaning. Wash the tray in warm sudsy water or in a dishwasher.
 7. The roller ring and oven cavity floor should be cleaned regularly to avoid excessive noise. Simply wipe the bottom surface of the oven with mild detergent, water or window cleaner and dry. The roller ring may be washed in mild sudsy water or dish washer. Cooking vapour collect during repeated use but in no way affect the bottom surface or roller ring wheels.
- When removing the roller ring from cavity floor for cleaning, be sure to replace it in the proper position.
8. Remove odors from your oven by combining a cup of water with the juice and skin of one lemon in a deep microwaveable bowl. Microwave for 5 minutes, wipe thoroughly and dry with a soft cloth.
 9. When it becomes necessary to replace the oven light, please consult a dealer to have it replaced.



INSTALLATION

Assemble indicator figure






INSTALLATION METHOD

1 :make sure the cabinet demision
as:566(depth)x550mm(width)x365mm(height)

2 :put the indicator chart paper into the cabinet ,and assemble
the orientation in the position with three screw ,this position has
marked in the indicator chart paper

Attention:


- 1.indicator chart should aligned with the left edge, right edge
and front edge
2. the orientation show fixed as picture 3



3: put the microwave oven into the cabinet .please keep the microwave oven the same distance with the left side and right side of the cabinet, and make sure the orientation insert the hold on the back of the microwave oven

4: after the position fixed ,then open the door of the microwave oven, then you can find a hole in the front of the cavity ,assemble the screw (4x35mm)to fix the microwave oven tightly in the cabinet ,fill the hold on the screw pin with the cap to finish the last step

Attention: cabinet back and bottom should keep a distance of not less than 100mm with the wall and floor in the kitchen



Warranty

THIS WARRANTY IS VALID IN AUSTRALIA ONLY

Note:

Please complete the following details when you have unpacked the product and retain this card with the purchase invoice or sales docket.

Warranty:

This product is covered by a Warranty in addition to all rights available to you by statute. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. **The Warranty is for a period of two years (24 months) from the date of purchase for Parts and Labour.** Refrigeration appliances will have an additional three years (36 months) Warranty for **Parts only** on the Sealed System eg; compressor, condenser, evaporator, filter dryer and pipe work, subject to the following conditions;

The conditions mentioned above are;

1. that the purchaser carefully follows all instructions packed with the product;
2. that the purchaser carefully follows the installation instructions provided and complies with the electrical wiring regulations, gas and/or plumbing codes;
3. that the purchaser carefully follows the instructions provided in the owner's handbook relating to the proper use and care of the product and does not use the product for any purpose other than the Domestic, indoor use, for which it has been designed.
4. that the product was purchased and installed in Australia;
5. that this Warranty does not extend to;
 - a) optional glass lids for hobs apart from claims which relate to mechanical or physical damage thereof at the date of purchase;
 - b) light globes (with the exception of microwave oven globes);
 - c) damage to ceramic glass caused by liquid or solid spillovers, lack of maintenance or impact. Please read the booklet explaining about liquids containing **sugar**;
 - d) damage to the surface coatings caused by cleaning or maintenance using products not recommended by the owners handbook;
 - e) defects caused by normal wear and tear, accident, negligence, alteration or misuse.
 - f) a product dismantled, repaired or serviced by any serviceperson other than an authorised employee or agent of Smeg Australia Pty Ltd;
 - g) The provision of service under this Warranty is limited by the boundary of the nearest agent's area. Travelling cost incurred for service outside this area is not covered by this Warranty and will incur commercial cost to be paid by the customer regulated by the number of kilometres travelled beyond the service area.

For service, please contact your local Smeg Australia Pty Ltd office or dealer/retailer from whom you purchased the product. If you are unable to establish the date of purchase, or if the fault is not covered by this Warranty, or if the product is found to be in working order, you will be required to bear all service call charges.

CONTACTS:

SYDNEY – HEAD OFFICE.....Tele. (02) 86674888. Fax. (02) 86674800
 QUEENSLAND.....Tele. (07) 32660444. Fax. (07) 32667511
 NEWCASTLE.....Tele. (02) 49609266. Fax. (02) 49609277
 CANBERRA.....Tele. (02) 62807099. Fax. (02) 62807137
 WAGGA WAGGA.....Tele. (02) 69228600. Fax. (02) 69228611
 VICTORIA.....Tele. (03) 90941999 Fax. (03) 90941990
 TASMANIA.....Tele. (03) 63348166. Fax. (03) 63348177
 SOUTH AUSTRALIA.....Tele. (08) 83461888. Fax. (08) 83401034
 WESTERN AUSTRALIA.....Tele. (08) 94780466. Fax. (08) 94780470

DETAILS:

Model No:.....
 Serial No:.....
 Date of Purchase:.....
 Retailer:.....
 Invoice/Docket No:.....

Smeg Australia Pty Ltd. ABN No.33 146 901 082. ACN No.146 901 082